






Mi Induction Cooker

-
- Dual-frequency continuous heating ensures steady, even cooking.
 - Consistent low temperature cooking delivers the perfect taste every time.
 - 2100-Watt power, 99-level adjustable heating gives you precise control to cook like a pro.
-
- Conventional stove-style knob provides simple, intuitive control and precise heat adjustment.
 - External temperature sensor for smart heat control.
 - More than 100 healthy cooking modes developed by professional nutritionists are also available through the Mi Home app.
-
- Easy-to-read OLED display shows current cooking mode and power level.
 - Includes 5 default cooking modes: Hotpot, Deep Fry, Steam & Boil, Simmer and Stir Fry.
 - Dual non-slip pads are durable and prevent slippage filtering invalid alarms.
-

Mi Induction Cooker



Conventional stove-style knob provides simple, intuitive control and precise heat adjustment



Instructions

1. To turn on the Mi Induction Cooker, first plug the power cord into an electrical outlet, then press and hold the control knob.
2. To start Wi-Fi mode, simultaneously hold down the Timer button and the Function button.
3. To select a cooking mode, turn the knob in either direction. After you've selected the mode you want, tap the OLED display to start cooking.
4. While cooking, turn the knob in either direction to increase or decrease the power level. To pause cooking at any time, simply tap the display.
5. More cooking modes are available through the Mi Home app. The Mi Induction Cooker can store up to 8 custom cooking modes at a time.
6. To turn off the Mi Induction Cooker, press and hold the OLED display.

Specifications

Model: DCL01CM
Color: White
Dimensions: 280 × 265 × 70 mm
Net Weight: Approx. 2.1 kg

Rated Power: 2100 W
Voltage / Rated Frequency: 220 V / 50 Hz
Gross Weight: Approx. 2.6 kg

